


DOWNLOAD

[Record Watch Company Serial Numbers](#)

PG. 12

<u>NUMBER</u>	<u>GRADE</u>	<u>DATE</u>	<u>NUMBER</u>	<u>GRADE</u>	<u>DATE</u>
796801-797200	974	1910	835001-835600	992L	1911
797201-797500	954	1911	835601-835800	990L	1911
797501-798000	974	1910-1911	835801-836000	974L	1911
798001-798500	990	1911	836001-836500	974P	1911
798501-798800	972	1911	836501-836900	954P	1911
798801-799000	974	1910	836901-837000	974P	1911
799001-799200	954	1910-1911	337001-838000	975P	1911
799201-799600	992	1911	838001-839000	975L	1911
799601-800000	954	1911	839001-839400	974L	1911
800001-802000	974	1911	839401-839700	992L	1911
802001-802200	954	1911	839701-840000	990L	1911-1912
802201-802202	972	1911	840001-840400	952L	1912-1913
802203-802300	954	1911	840401-840900	950L	1911-1912
802301-802500	972	1911	840901-841000	952L	1913
802501-803700	974	1911	841001-842000	975P	1911
803701-804200	954	1911	842001-843000	974L	1911-1912
804201-806000	974	1911	843001-844000	974P	1911-1912
806001-807000	975	1911	844001-844200	993	1911-1912
807001-807500	993	1911	844201-845000	975	1911-1912
807501-808800	975	1911	845001-845200	992	1911-1912
808801-809000	993	1911	845201-845400	972	1911
809001-809500	974	1911	845401-845700	954	1911
809501-809600	972	1911	845701-846000	972	1912
809601-810000	974	1911	846001-846500	952	1913-1914
810001-810300	990	1911	846501-847000	950	1912-1913
810301-812000	974	1911	847001-847200	972	1912
812001-812700	992	1911	847201-849000	974	1911-1912
812701-813000	974	1911	849001-850000	975	1911-1912
813001-814000	974P	1911	850001-850300	992	1911
814001-814800	974L	1911	850301-850800	990	1912
814801-815900	992	1911	850801-851000	972	1912
815901-816000	974L	1911	851001-851400	993	1911-1912
816001-817000	974P	1911	851401-852000	975	1911-1912
817001-819000	974L	1911	852001-853000	992	1911-1912
819001-820000	974P	1911	853001-854000	974	1912
820001-821500	974L	1911	854001-854600	950	1912-1913
821501-822000	990L	1911	854601-854900	952	1913-1914
822001-822700	992L	1911	854901-855100	960L	1912
822701-823000	974L	1911	855101-856000	950L	1913
823001-824000	974P	1911	856001-857840	975	1912
824001-826000	975P	1911	857841-858000	975L	1912
826001-826500	975L	1911	858001-858500	974	1912
826501-827000	993	1911	858501-859000	972	1912
827001-828000	975P	1911	859001-860000	974	1912
828001-829000	974L	1911	860001-862300	992	1912
829001-830000	974P	1911	862301-862400	954	1912
830001-830500	990L	1911	862401-862500	972	
830501-831000	992L	1911	862501-862600	954	1912
831001-831100	954P	1911	862601-862800	972	1912
831101-831200	972P	1911	862801-863000	974	1911-1912
831201-831500	954P	1911	863001-864000	992	1912
831501-832000	974P	1911	864001-865000	975P	1912
832001-832400	974L	1911	865001-866000	992	1912
832401-833000	992L	1911	866001-866600	974	1912
833001-834000	990L	1911	866601-866700	954	1912
834001-834600	974P	1911	866701-867000	972	1912
834601-834800	974L	1911	867001-868000	975	1912
834801-835000	974P	1911	868001-869000	992	1912

[Record Watch Company Serial Numbers](#)

DOWNLOAD

Renaissance Watch Repair is not affiliated with the Longines company. The Longines name and names of various Longines watch models are trademarks of Longines and the Swatch Group, and are shown herein for educational purposes only. Raw jewels alone cost little; it's their incredibly precise finish and their perfect positioning in the watch that give them value and make your watch run so dependably. Longines is also the official timer of the World Air Sports Federation, and has provided the timing equipment used to verify world aviation records, including Lindbergh's historic first non-stop solo crossing of the Atlantic. A run can consist of a hundred or less up to tens of thousands per group. The total run quantity of a model or grade is the complete number assembled before the factory ceased production of that model. Adjusted An "adjusted" movement is one that is finished or specially "tuned" at the factory for certain applications. This method of production proved to be very successful, and by the early 1900's the Longines factory employed over 1000 people and had achieved worldwide distribution and success with its products. Francillon wanted to modernize the production of watches and believed that bringing all the final assembly and finish operations together into one factory would be a more efficient method of production. | Vintage Watches Repair | Watch Parts Branded | Watch Parts Non Branded | | Watches for Sale | Vintage Watches Restoration | About Blancpain. Going barrel is the form used in modern watches, is wound by turning the arbor and drives the watch movement by a ring of teeth around the barrel. e10c415e6f